

Model: All Nokia

- 1 - Switch ON your phone without SIM Card,
- 2 - Compose #PW+CODE+1#

(if locked from Fido/Roger Canada, please compose#PW+CODE+7#)

The letter P appear after press 3 times quickly the button star (*)

The letter W appear after press 4 times quickly the button star (*)

The letter + appear after press 2 times quickly the button star (*)

- 3 - The phone show "SIM Restriction Off" and was unlocked !

Model: Nokia C3

Turn on the phone with a non-accepted SIM card inserted. It should state that the SIM is restricted.

Press OK to be able to enter the unlock code. Then, using the full QWERTY keypad as normal, type: #pw+CODE+1# and press OK

Note: replace CODE with the unlock code we send you